

LEXUS NX (Hybrid)

year: 2017 →

with and without Keyless System

program №: 12851

from: 2022-04-25

connector 8 pin							
CAN H	CAN L	CAN H	CAN L	CAN H	CAN L	OUT +	OUT -
CAN1-H	CAN1-L	CAN2-H	CAN2-L	CAN3-H	CAN3-L	Alternative blink control	Alt. contr. centr. lock
1	2	3	4	5	6	7	8
+	+	+	+	+	+	+	+

connector 15 pin														
OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT
Driver door sensor	Passengers door sensor	Trunk lid	Hood sense	Original alarm++	Arming state	Lock factory remote	Unlock factory remote	Any button pressed	Handbrake / Parking	Speed 10kmph	Engine running	Engine speed (RPM)	Ignition	Key inserted
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

connector 10 pin									
OUT	IN	IN	IN	IN	IN	IN	IN	IN	IN
Footbrake	Drivers door opening sim.	Turn off the engine	Turn on the engine	Turn signal control	Trunk release	Opening all doors	Closing all doors	GND	PWR +12V
1	2	3	4	5	6	7	8	9	10
+	+	+	+	+	+	+	+	+	+

Contr. of factory alarm	Contr.c.lock. when ign.is on	Comfort closure
+	+	+

Attention:

Switches

LEXUS NX

year: 2014 →

with and without Keyless System

program №: 11893

from: 2020-08-14

connector 8 pin							
CAN H	CAN L	CAN H	CAN L	CAN H	CAN L	OUT +	OUT -
CAN1-H	CAN1-L	CAN2-H	CAN2-L	CAN3-H	CAN3-L	Alternative blink control	Alt. contr. centr. lock
1	2	3	4	5	6	7	8
+	+	+	+	+	+	+	+

connector 15 pin														
OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT
Driver door sensor	Passengers door sensor	Trunk lid	Hood sense	Original alarm++	Arming state	Lock factory remote	Unlock factory remote	Any button pressed	Handbrake / Parking	Speed 10kmph	Engine running	Engine speed (RPM)	Ignition	Key inserted
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

connector 10 pin									
OUT	IN	IN	IN	IN	IN	IN	IN	IN	IN
Footbrake	Drivers door opening sim.	Turn off the engine	Turn on the engine	Turn signal control	Trunk release	Opening all doors	Closing all doors	GND	PWR +12V
1	2	3	4	5	6	7	8	9	10
+	+	+	+	+	+	+	+	+	+

Contr. of factory alarm	Contr.c.lock. when ign.is on	Comfort closure
+	+	+

Attention:

Switches

LEXUS NX (Hybrid)

year: 2014 →

with and without Keyless System

program №: 13415

from: 2022-03-07

connector 8 pin							
CAN H	CAN L	CAN H	CAN L	CAN H	CAN L	OUT +	OUT -
CAN1-H	CAN1-L	CAN2-H	CAN2-L	CAN3-H	CAN3-L	Alternative blink control	Alt. contr. centr. lock
1	2	3	4	5	6	7	8
+	+	+	+	+	+	+	+

connector 15 pin														
OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT
Driver door sensor	Passengers door sensor	Trunk lid	Hood sense	Original alarm++	Arming state	Lock factory remote	Unlock factory remote	Any button pressed	Handbrake / Parking	Speed 10kmph	Engine running	Engine speed (RPM)	Ignition	Key inserted
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

connector 10 pin									
OUT	IN	IN	IN	IN	IN	IN	IN	IN	IN
Footbrake	Drivers door opening sim.	Turn off the engine	Turn on the engine	Turn signal control	Trunk release	Opening all doors	Closing all doors	GND	PWR +12V
1	2	3	4	5	6	7	8	9	10
+	+	+	+	+	+	+	+	+	+

Contr. of factory alarm	Contr.c.lock. when ign.is on	Comfort closure
+	+	+

Attention:

Switches

LEXUS RC (Hybrid)

year: 2019 →

with and without Keyless System

program №: 14273

from: 2022-07-14

connector 8 pin							
CAN H	CAN L	CAN H	CAN L	CAN H	CAN L	OUT +	OUT -
CAN1-H	CAN1-L	CAN2-H	CAN2-L	CAN3-H	CAN3-L	Alternative blink control	Alt. contr. centr. lock
1	2	3	4	5	6	7	8
+	+	+	+	+	+	+	+

connector 15 pin														
OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT
Driver door sensor	Passengers door sensor	Trunk lid	Hood sense	Original alarm++	Arming state	Lock factory remote	Unlock factory remote	Any button pressed	Handbrake / Parking	Speed 10kmph	Engine running	Engine speed (RPM)	Ignition	Key inserted
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

connector 10 pin									
OUT	IN	IN	IN	IN	IN	IN	IN	IN	IN
Footbrake	Drivers door opening sim.	Turn off the engine	Turn on the engine	Turn signal control	Trunk release	Opening all doors	Closing all doors	GND	PWR +12V
1	2	3	4	5	6	7	8	9	10
+	+	+	+	+	+	+	+	+	+

Contr. of factory alarm	Contr.c.lock. when ign.is on	Comfort closure
+	+	+

Attention:

Switches

LEXUS RC

year: 2016 →

with and without Keyless System

program №: 11338

from: 2017-09-01

connector 8 pin							
CAN H	CAN L	CAN H	CAN L	CAN H	CAN L	OUT +	OUT -
CAN1-H	CAN1-L	CAN2-H	CAN2-L	CAN3-H	CAN3-L	Alternative blink control	Alt. contr. centr. lock
1	2	3	4	5	6	7	8
+	+	+	+	+	+	+	+

connector 15 pin														
OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT	OUT
Driver door sensor	Passengers door sensor	Trunk lid	Hood sense	Original alarm++	Arming state	Lock factory remote	Unlock factory remote	Any button pressed	Handbrake / Parking	Speed 10kmph	Engine running	Engine speed (RPM)	Ignition	Key inserted
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

connector 10 pin									
OUT	IN	IN	IN	IN	IN	IN	IN	IN	IN
Footbrake	Drivers door opening sim.	Turn off the engine	Turn on the engine	Turn signal control	Trunk release	Opening all doors	Closing all doors	GND	PWR +12V
1	2	3	4	5	6	7	8	9	10
+	+	+	+	+	+	+	+	+	+

Contr. of factory alarm	Contr.c.lock. when ign.is on	Comfort closure
+	+	+

Attention:

Switches

